



PRE-STARTUP CLEANING PROCEDURE FOR 8 inch PURON[®] MP HOLLOW FIBER CARTRIDGES

The following cleaning procedure must be performed prior to initial use of cartridges and whenever system has been inoperative for more than seven (7) days. This procedure will remove storage solution and condition the membrane for production. Failure to follow this procedure may lead to poor performance and will void cartridge warranty. Product data sheet is to be reviewed before conditioning so cartridges are always operated within required pressure, flows, and other required parameters. Please refer to attached KMS Water Quality Guidelines for clean water requirements.

Step 1. Rinses	Ambient Temp	10-15 min.
-----------------------	---------------------	-------------------

Fill cartridges (feed and permeate) using feed water and rinse 3x with clean water (50-80°F/10-27°C) in the following manner:

1. Backflush at 19 gpm (4.3 m³/hr) /cartridge for 30 seconds
2. Drain feed side of cartridges
3. Fill feed side of cartridges at less than 20 gpm (4.5 m³/hr) /cartridge

Step 2. Chlorine Cycle	Max pH 10.5/Max. 100°F	75-90 min.
-------------------------------	-------------------------------	-------------------

Circulate heated water (65-80°F/18-27°C) through system under standard pressure and flow conditions.

Add liquid, membrane grade sodium hypochlorite (NaOCl) to achieve 450-500 ppm total chlorine concentration.

Circulate solution through the membranes cartridges in a permeation mode at 11 gpm (2.6 m³/hr) /cartridge for 50-60 minutes.

Drain, then rinse per Step 1 until the free chlorine concentration is below 3 ppm or less based on downstream permeate requirements

*For technical assistance, please contact Technical Service at (978) 694-7050.
To place an order, please call our Customer Service Department at (978) 694-7005.*

KMS WATER QUALITY GUIDELINES FOR CLEANING & DIAFILTRATION

For All Polymeric Membrane and Ion Exchange/Adsorbent Resin Applications

Parameter	<u>MF/UF</u>	<u>NF/RO & IE/Abs. Resin</u>
Turbidity	< 1.0 NTU	< 1.0 NTU
Suspended Solids (see Note 1)	< 5 mg/l	< 1 mg/l
Calcium (Ca)	< 10 mg/l	< 5 mg/l
Total Hardness (as CaCO₃)	< 60 mg/l	< 30 mg/l
Iron (Fe)	< 0.05 mg/l	< 0.05 mg/l
Zinc (Zn)	< 0.3 mg/l	< 0.05 mg/l
Copper (Cu)	< 0.1 mg/l	< 0.05 mg/l
Manganese (Mn)	< 0.05 mg/l	< 0.02 mg/l
Aluminum (Al)	< 0.05 mg/l	< 0.05 mg/l
Silica, Reactive (as SiO₂)	< 10 mg/l	< 10 mg/l
Silica, Colloidal (as SiO₂)	< 1 mg/l	< 0.1 mg/l
Silicone	0 mg/l	0 mg/l
Total Bacteria Count (TBC)	< 1000 per ml	< 1000 per ml
E-Coli Count	0 per 100 ml	0 per 100 ml
Chlorine (as NaOCl)	< 1 mg/l	0 mg/l
D-Limonene (citrus applications only)	< 5 mg/l	0 mg/l
Fats, Oils and Grease	0 mg/l	0 mg/l
Total Organic Carbon (TOC)	< 1 mg/l	< 1 mg/l
pH (standard units)	6.5 – 7.5	6.5 – 7.5

1. The water supply must be free from particulate matter such as rust, scale, flakes, sandy and granular material, slurries, scum, algae and any chemical constituents that could foul or damage the membranes.
2. The water pH may need to be adjusted with acid or alkali depending on application and local conditions.
3. KMS membranes are available in many configurations and materials that may be affected differently by various water constituents. Softened water or evaporator condensate is generally acceptable for cleaning and flushing of polymeric membranes. Please consult with the KMS Process Group for the particular membrane in question.

PRE-STARTUP CLEANING PROCEDURE FOR 8 inch PURON[®] MP HOLLOW FIBER CARTRIDGES

The information contained in this publication is believed to be accurate and reliable, but is not to be construed as implying any warranty or guarantee of performance. We assume no responsibility, obligation or liability for results obtained or damages incurred through the application of the information contained herein. Refer to Standard Terms and Conditions of Sale for additional information.

Koch Membrane Systems, Inc., www.kochmembrane.com

Corporate Headquarters: 850 Main Street, Wilmington, Massachusetts 01887-3388, US, Tel. Toll Free: 1-888-677-5624, Telephone: 1-978-694-7000, Fax: 1-978-657-5208
European Headquarters: Koch Chemical Technology Group Ltd., Units 3-6, Frank Foley Way, Stafford ST16 2ST, GB, Telephone: +44-178-527-2500, Fax: +44-178-522-3149

• Aachen DE • Lyon FR • Madrid ES • Milan IT • Wijnegem BE • Beijing & Shanghai CN • Mumbai & New Delhi IN • Melbourne & Sydney AU • Singapore • Sao Paulo BR • Dubai UAE •

For related patent and trademark information, visit www.kochmembrane.com/legal
Koch Membrane Systems, Inc. is a Koch Chemical Technology Group, LLC Company.